

STERIJET

ST200



NEBULIZZATORE AUTOMATICO PER DISINFETTARE
PIEDI E CALZATURE

AUTOMATIC ATOMISER FOR FEET AND SHOES SANITIZING

HYGIENE SOLUTION
STERIGAM

DESCRIZIONE *DESCRIPTION:*

Questo modello è equipaggiato di un supporto mobile, che permette di collocare l'apparecchio dove lo si ritiene necessario evitando di fissarlo alla parete.

This version is equipped with a mobile support on blue wheels, allowing to use and place the atomiser wherever it is required.

FUNZIONAMENTO *FUNCTIONING:*

Avvicinare il piede o la calzatura all'interno dell'apposito vano dove una fotocellula aziona automaticamente il rapido processo di nebulizzazione del liquido igienizzante.

La maniglia è studiata per aiutare le persone a mantenere l'equilibrio durante il processo di disinfezione dei piedi o delle calzature.

Approach your feet or footwear to the opening and to start atomisation process.

The device's handle is especially designed to help people in keeping their balance during the sanitising process of feet or footwear.

This unit has a 1.5 Lt. inside tank allowing feet or footwear sanitising for approx. 150 people.



SUPPORTO MOBILE - MOBILE SUPPORT



**ELECTRIC
MODEL**



TECHNICAL DATA

TENSIONE DI ALIMENTAZIONE:	115/230 V 50/60 HZ
TENSIONE DI ESERCIZIO:	12 V
CAPACITÀ DEL SERBATOIO:	1500 CC
ASSORBIMENTO :	40 W
PESO:	14,5 KG