

STERIJET

ST100



NEBULIZZATORE AUTOMATICO PER DISINFETTARE
PIEDI E CALZATURE
AUTOMATIC ATOMISER FOR FEET AND SHOES SANITIZING

HYGIENE SOLUTION
STERIGAM

DESCRIZIONE *DESCRIPTION:*

E' un nebulizzatore elettronico automatico studiato per ottenere una rapida disinfezione dei piedi e delle calzature.

E' alimentato a 230 Volt - 12 Volt.

E' ideale per essere utilizzato nei centri benessere, piscine, centri estetici, impianti balneari e termali, hotel, ospedali, industrie farmaceutiche e settore agroalimentare.

Un serbatoio di capacità pari a 1,5 litri permette di disinfettare i piedi o le calzature di circa 200 persone.

Electrical atomiser especially designed for a quick and safe sanitising of feet and footwear.

Power supply: 115/230 Volt - 12 Volt.

An ergonomic and functional design combined with a high-quality performance are the main features of Sterijet. Sterijet assures the hygiene in both professional and sports fields.

It is especially recommended for use in fitness centres, beauticians, swimming pools and bathing establishments, gyms, doctor's surgeries, hotels and hospitals.

FUNZIONAMENTO *FUNCTIONING:*

Avvicinare il piede o la calzatura all'interno dell'apposito vano dove una fotocellula aziona automaticamente il rapido processo di nebulizzazione del liquido igienizzante.

La maniglia è studiata per aiutare le persone a mantenere l'equilibrio durante il processo di disinfezione dei piedi o delle calzature.

Approach your feet or footwear to the opening and to start atomisation process.

The device's handle is especially designed to help people in keeping their balance during the sanitising process of feet or footwear.

This unit has a 1.5 Lt. inside tank allowing feet or footwear sanitising for approx. 150 people.



SUPPORTO A PARETE - WALL BRACKET



**ELECTRIC
MODEL**



TECHNICAL DATA

TENSIONE DI ALIMENTAZIONE:	115/230 V 50/60 HZ
TENSIONE DI ESERCIZIO:	12 V
CAPACITÀ DEL SERBATOIO:	1500 CC
ASSORBIMENTO :	40 W
PESO:	8,5 KG